

Vibrating Cock Rings

Instructions

Before Use

1. Fully charge for about
2. hours. Rinse it with clean water or mild detergent then dry with towel but avoid direct contact between water and charging port.

Direction for Use

1. Gently put on the base of penis, balls or both, and adjust it to find the pleased feeling.
2. Set to the mode that you find exciting about and let it vibrate.
3. Any confusion please refer back to the demonstrated video or contact us.

After Use

1. Rinse it with clean water and sterilize it, then dry with towel or let it air dry.
2. Avoid direct sunshine and keep it out of reach of children or pets.

Precautions

1. Stop using the product if it is found to have a deformed surface.
2. The product is only aimed to people over 18 years old.